

How to connect a GARMIN to the NX2 Server.

SETUP GARMIN:

- I/O Setup:
NONE / NMEA
0183 V1.5
4800 baud
- Heading => True

GARMIN

RED

X-wire

BLACK

NOTE!

X-wire = **BLUE**, when connecting a "fixed" Garmin.
e.g. Garmin 120XL/128 etc.
X-wire = **BROWN**, when connecting a handheld
Garmin e.g. Garmin 45XL/12XL/48 etc.

